

## IR Codes for Universal Remote Control

LS60 Wireless II work with Universal programmable remote control provided that remote control manufacturers have implemented KEF IR command codes in their remote controls.

The following tables list the command codes required.

		Code Format:	NEC
		Factory Code:	0x01
#	Functions	Function codes	
1	Power On/Off Toggle	0x40	
2	Mute/ Unmute Toggle	0x20	
3	Play/Pause	0x18	
4	Forward	0x52	
5	Next Source	0x58	
6	Volume Up	0x60	
7	Volume Down	0xA0	
8	Backward	0xD2	
9	Power ON	0x38	
10	Power OFF	0x3A	
11	Mute	0x48	
12	Un-Mute	0x4A	
13	Source: Wi-Fi	0x30	
14	Source: Bluetooth	0x2A	
15	Bluetooth Pairing	0x98	
16	Source: AUX	0x02	
17	Source: Optical	0x0A	
18	Preset Volume (30%)	0x78	
19	Source: HDMI	0x88 0x8A	
20	Source: Coaxial	0xE0	
21	Previous Source	0xD0	